




Buy it for looks. Buy it for life.®


## Illustrated Parts

### ■ Order by Part Number



### PureTouch® Single Control Kitchen Faucet with Water Filter & Pullout Spray

MODEL	HANDLE TYPE	FINISH
<b>DISCONTINUED SKUS</b>		
7850	Lever	Chrome
7850S	Lever	Sand
7850W	Lever	Glacier



**Please Note: For under the deck parts, service kits, and valve bodies, you must refer to the following page.**

• Note - Battery & Screw  
Replacement Instructions: INS133A