

# 24V LED LIGHTBAR ACCESSORIES

LED LIGHTBAR 90+ AND LIGHTBAR PRO 90+



Power Line Interconnector  
**NAL-208** 20" Cable  
**NAL-208/72** 72" Cable  
**NAL-212** 12" w/ Switch



90° Power Line Interconnector  
**NAL-207** 20" Cable  
**NAL-207/72** 72" Cable



Mini Power Feed Splitter  
**NAL-221**  
 One in and four out



\*Flexible Extension Cord  
**NRA-125/6** 6" Cable  
**NRA-125/12** 12" Cable  
**NRA-125/18** 18" Cable  
**NRA-125/72** 72" Cable  
 Use with NATL-530HW,560HW  
 to connect to NUSP-Jbox



Flexible Power Cord  
**NRA-6035W/6** 6'  
**NRA-6035W/10** 10'  
 use with NATL-530HW,560HW



Mini Coupler  
**NAL-220**



**NEW!**  
 Dimmable Class II Remote  
 Hardwire Magnetic Driver  
 with Integral Regulator for  
 Constant Current & Voltage  
**NMTD-60/24D\*** 60W  
**NMTD-96/24D\*** 96W  
 Includes NALTL-10 · 120/277V input



Dimmable Class II Remote  
 Hardwire Magnetic Driver  
 with Integral Regulator for  
 Constant Current and Voltage  
**NMT-303/24C2D1\*†**  
 3x100W  
 Includes (3) NALTL-10



Hardwired Class II  
 Electronic Driver  
**NATL-530HW\*** 30W  
**NATL-560HW\*** 60W  
 Requires NUSP-JBox or  
 NRA-6035



Class II Electronic LED  
 Driver  
**NATL-5060HW\*** 60W  
**NATL-5100HW\*** 100W  
 Includes NALTL-10



Plug-In Electronic Driver  
**NATL-524\*** 24W 24V DC  
**NATL-545\*** 45W 24V DC  
**NATL-596\*** 96W 24V DC



Power Line Connector  
**NALTL-10** 10' Cable  
**NALTL-30** 30' Cable  
**NATL-302** 5" Splitter



Low Voltage Splice Box  
**NATL-415W**



Junction Box for Hard  
 Wiring  
**NUSP-JBox**



Dimmer  
**NAL-250**

\*Requires power line interconnector to power lightbar unless using NAL-230 or NAL-255.  
 Due to unknown ambient temperatures, Nora recommends de-rating drivers by 20%