

CATALOG NUMBER

ECCS2

electricCenter

ACCESSORIES

250 kcmil Collar Strap

Wire Range: #6 AWG - 250 kcmil

For use on "GB" type ground bars only

Same As:

■ CS2



INSTALLATION INSTRUCTIONS



DANGER

Hazardous Voltage.
Will cause death, serious injury
or substantial property damage.

Turn off power supplying this
equipment before working inside.




SAFETY INSTRUCTIONS

Collar Strap:

Wire Range: #6 AWG - 250 kcmil

Tightening Torque: 250 lb.-ins.



NOTE: This instruction outlines the recommended installation procedure.

1. Turn off and lock off the power supplying this equipment before working inside.
2. Loosen 3 screws on ground bar at desired location of collar strap.
3. Insert the feet of the collar strap into ground bar and tighten the screws in Step 2 to 45 lb.-ins.

4810402 Rev.A