

CATALOG NUMBER

# ECHS125

electricCenter  
ACCESSORIES

## 1-1/4" HS Hub

Same As:

- |          |          |
|----------|----------|
| ■ HS125  | ■ EHS125 |
| ■ HS125M | ■ HS125U |



### INSTALLATION INSTRUCTIONS



#### DANGER


**Hazardous Voltage.**  
Will cause death,  
serious injury or substantial  
property damage.

Turn off power supplying this  
equipment before working inside.

#### SAFETY INSTRUCTIONS

**Note:** This instruction outlines the recommended installation procedure.

1. Turn off and lock off the power supplying the load center before working inside.
2. Obtain gasket from cover plate bag and place on enclosure head along with hub. Gasket is not required if all holes are extruded up.
3. If "X" dimension in Fig. 1 is 3 9/16" use two (2) of the four (4) screws furnished with hub in the back mounting positions. Use the two (2) screws furnished in poly bag with enclosure in the front mounting positions to attach hub to head. If "X" is less than 3 9/16" use the four (4) screws furnished with hub to attach hub to head. Short screws not required on side-hinged door.
4. Tighten screws to 35-40 lb.-in.



4810421 Rev.A